



ASSEMBLY AND OPERATING INSTRUCTIONS

CONTENTS

I About The Product


1-1	Product Information	2
1-2	Parts List	4

III Appendix

3-1	User's Manual	13
3-2	After-sales Service	14
3-3	Disclaimer	14
3-4	Custom Canopy	15
3-5	More Products	17

II Installation

2-1	Before assembly	5
2-2	Safety Tips	5
2-3	Setting up	6
2-4	Taking down	10



Product Information

Product Name	POP UP CANOPY
Color	White
Top Material	Polyester
Bracket Material	Alloy Steel
Specifications	10 ft x 15 ft
Applicable Season	Four Seasons
Applicable Venue	Beach, Party, Commercial Events, Sports Activities



FS01

P3




P3




FS02

PARTS LIST

Part#		Qty
P1		1
P2		1
P4		1
P5		4
P6		4
P7		4

FRAME PART NUMBER

A	Dome cap	H	Upper peak pole bracket
B	Foot pad	I	Lower peak pole bracket
C	Inner leg	J	Outer leg w/ velcro
D	Joint bolt / nut / washer	K	Inner leg height adjuster
E	Joint bolt / nut / washer & bolt cap	L	Truss bar
F	2 Way outer leg bracket	M	Peak pole upper
G	2 Way outer leg slider bracket	N	Peak pole lower



Tips: Any requests for replacing or purchasing the replacement parts, please contact us by email and tell us the Part Number you need.

BEFORE ASSEMBLY



2 PERSON



10-20 MIN ASSEMBLY



HAMMER

SAFETY TIPS

1. Please read this manual thoroughly and carefully before assembling and using the item, follow all instructions and keep the manual for future reference.
2. Proper use of the item includes observing the safety instructions in this manual and the information on the proper use of the item outdoors and for private purposes.
3. If any parts are missing, broken, damaged or worn, do not use this product until repairs have been made and/or factory replacement parts have been installed.
4. Do not use this item in a way not recommended by the manufacturer, as any damage caused will not be covered by the warranty.
5. Non-compliance with the general and safety instructions in this manual may result in personal injury and/or serious damage to the item. We shall not be liable for any such loss.
6. Place the item on a stable and level surface.
7. Do not use or store this item close to open flames or flammable/combustible chemicals.
8. Be careful not to pinch hands or appendages during assembly.
9. Do not attempt to assemble this item under the following circumstances: Drunk/Inclement weather/Lack of tools or parts/Without assistance

SETTING UP (10X15)




► Step 1

Remove frame from box and stand upright in the center of the desired setup location.

Step 2 ◀

Gently pull the outer legs until the frame is partially expanded.



SETTING UP (10X15)

Step 3 ◀

Attach the canopy top to each frame corner with velcro straps.



▶ Step 4

Lift the frame into position by expanding the truss bars until frame is fully expanded. Attach the velcro straps on the truss bar.

Tips: Please note that the **red peak tensioner** is used to adjust the issue of the top becoming loose after prolonged use. When hearing crack, it means it comes the top. New products do not require adjustment.



SETTING UP (10X15)



► Step 5

Adjust the frame legs to your desired height.



Step 6 ◀

Use sandbags, ropes and stakes for fixation.

Tips: Filled the sandbags with sand, rock, gravel, snow, dirt or other contents.
Use hammer to anchor the stakes if necessary.



TAKING DOWN (10X15)

Step 1 ◀

Remove stakes, ropes and sand bags securing the canopy to the ground.



▶ Step 2

Position the legs to its lowest position by adjusting the slider bracket. Carefully pick down the velcro straps on the truss bar.



TAKING DOWN (10X15)



► Step 3

Slightly lift the frame and push slowly until about ½ way closed.

Step 4 ◀

Carefully pick down the velcro straps on each frame corner and put away the canopy top.


Tips: when taking this step, please don't put too much strength to avoid tearing.



TAKING DOWN (10X15)

Step 5 ◀

Push the frame into fully closed.



▶ Step 6

Store the frame back in the roller bag.



USER'S MANUAL

- It is recommended that you use the ropes and stakes to secure the canopy.
- This product is not intended to withstand periods of extreme/high wind or storm.
- Check the connection of the frame regularly to ensure that it is firm and stable.
- If the frame structures have water stains, please clean up with a soft cloth in time to prevent rust.
- When not in use, please remain closed and stored away to avoid potential damage.

AFTER-SALES SERVICE

About returns and refunds

Items shipped from our shop, also can be returned within 30 days of delivery. If the reason for return is a result of an error or a damage on product, we will provide a pre - paid shipping label. If the reason for return is personal dislike or improper size, you need afford the extra returning fee.

Pictures may be required for some returns to ensure an item is not damaged prior to its return.

Product Support

The warranty of our product is **ONE YEAR** after-sale protection for frame, **SIX MONTHS** after-sale protection for fabrics and accessories (**NOT INCLUDE** damage caused by improper personal use and bad weather). If you need help with using your product or if it doesn't work correctly, please feel free to contact us through Amazon. Pictures or Videos may be required to ensure which part is damaged or doesn't work.

DISCLAIMER

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

CUSTOM ABCCANOPY

The Pop Up Canopies can be customized to fit your needs. Add a custom top , walls or banner to make a bold statement. We offer digital dye sublimation and silk screened printing and up to 100% full print coverage in vivid images and precision clarity without compromise. We also offer Custom Table Cover, Feather Flag, Teardrop Flag.



CUSTOM WORKS



Pop Up Canopies



Table Cover



Teardrop Flag



Side Walls

MORE PRODUCTS



Embrace the Joys of Life

